



Quick Guide

GD-HW-APSV04T

GD-HW-APSV05T

GD-HW-APSV06T



Safety



Safety Manual

<https://download.grundig-security.com/Grundig-Product-Safety-2024-04-24-V1.pdf>

Legal Disclaimer




<https://grundig-security.com/terms-of-use/without prior notice>

1 Appearance Description

Frontside:



Rearside:



2 Installation

2.1 Start the PC

Connect the supplied USB-Keyboard and USB-Mouse to the front or rear USB-ports on the server.

After supplying the server with electricity press the ON/OFF-switch on the front. The server boots up and the Windows notifying window appears.

The Windows Log-In is:

User: **Grundig**

Password: **1234**

2.2 Start C-WERK

Start the C-WERK by double clicking onto the C-WERK icon.



The following window appears:



Log in with **root/root**

then click on

Connect

For detailed information of the operation of the C-WERK software please refer to the following link:

<https://doc.c-werk.com/display/encwerk/Documentation>