



## User Guide

GD-ML-BP3230HD

EN

[grundig-security.com](http://grundig-security.com)

**GRUNDIG**

# Content

<b>1. Important Safety Instructions</b>	<b>3</b>
<b>2. Installation Instructions</b>	<b>5</b>
<b>3. Package Content</b>	<b>6</b>
<b>4. Connections</b>	<b>6</b>
<b>5. Usage of the Monitor</b>	<b>7</b>
<b>6. OSD Menu Configuration</b>	<b>8</b>
<b>7. OSD Menu</b>	<b>8</b>
<b>8. Frequently Asked Questions</b>	<b>11</b>

---

This User Guide applies to the following GRUNDIG Model:  
GD-ML-BP3230HD

## **1. Important Safety Instructions**

Make sure that you only use the power adapter that is specified in the specifications sheet of the product. If you use any other adapter or connect the power supply incorrectly, this may cause explosion, fire, electric shocks or damage the product. Do not connect several devices to one power adapter as this may cause an adapter overload and can lead to over-heating and fire. Make sure that the plug of the power adapter is firmly connected to the power socket.

Do not place containers with liquids on the product. Do not place conducting items like tools, screws, coins or other metal items on the product. These may fall from the product or can cause fire or electric shocks or other physical injuries.

Do not push or insert any sharp items or any objects into the device as this may cause damage to the product, fire, electric shocks and/or physical injuries.

Do not block any ventilation openings, if there are any. Ensure that the product is well ventilated to prevent any over-heating.

Do not subject the device to physical shock or drop the product. If the product uses batteries, please use a battery type that is recommended by the manufacturer. Improper use or replacement of the battery may result in the hazard of explosion.

Do not use any accessories that are not recommended by GRUNDIG. Do not modify the product in any way.

If the product starts to smell or smoke comes out of the device, immediately stop using the product and disconnect it from the power supply to prevent fire or electric shocks. Then contact your

dealer or the nearest service center.

If the product does not work correctly, contact your dealer or nearest service center. Never open, disassemble or alter the product yourself. GRUNDIG cannot accept any liability or responsibility for problems caused by attempted and unauthorized repair and maintenance.

## **2. Installation Instructions**

Do not install the product near radiation sources. Do not install the product near heat sources, like radiators or other equipment that produces some heat.

Do not install the product in very cold or hot temperatures (please refer to the working temperature specified in the specification sheet of the product), dusty, dirty or damp environment.

Never touch the screen directly with your fingers. The acidic sweat of the fingers may be difficult to remove and you may damage the screen.

Do not touch the surface of the screen with sharp or abrasive items (like pens or screwdrivers), as this could scratch the display.

The monitor is only for indoor use. Please do not install it in an environment where it is exposed to oil, vapor, steam, moisture and dust, but in a clean environment with low humidity.

Do not apply any pressure to the monitor screen as the screen may break.

Do not install the monitor in a location that is exposed to direct

sunlight, dust, mechanical vibration or shock.

Always place the monitor on a flat surface.

Connect the power supply to the socket and plug the video cable or HDMI/VGA cable to the desired signal source.

Disconnect the power plug from the power outlet under the following conditions:

- If you will not use it for an indefinite period of time.
- When the power cord or plug is damaged or frayed.
- If the product has been dropped or the cabinet has been damaged.
- If the product exhibits a distinct change in performance, this indicates a need for service.

To clean the monitor's plastic case and display, a soft, lint-free cloth can be used. Do not use any cleaning materials with abrasive surfaces like scrub pads to clean your monitor.

To clean the display, a slightly damp cloth may be used to clean off fingerprints or smudges. Please unplug the monitor first before attempting cleaning with a damp cloth.

To clean the plastic case, a mild detergent may be used to clean the surface. But please do not use too much detergent or water as this could leak into the interior of the monitor. Please unplug the monitor first before attempting cleaning with a detergent or water.


Do NOT use any liquid cleaners based on alcohol, methylated spirit or ammonia or aerosol cleaners, as this may damage any coating present on the glass surface of the monitor. Use only mild soap or detergent with water or special cleaners for cleaning glass panels.

### 3. Package Content

1x Monitor, 1x User manual, 1x Remote Controller, 1x HDMI Cable,  
1x Power Cord

### 4. Connections

#### View of the Rear Interface:



**DC:** Connect the power cord that is included in the package.

**HDMI (High Definition Multimedia Input):** Supports digital video and audio connections.

**Note:** HDMI includes not only the image transfer but also the ability to transmit audio.

**VGA:** 15 pin D-sub cable for standard VGA connection.

**BNC IN:** Connect a video source with coaxial cable (with Composite Video Signal) to the BNC connector.

**BNC OUT:** Composite video loop through output – connect a second monitor.

**AUDIO IN:** 3.5 mm stereo jack connection for audio input when using VGA /AV connector.

## 5. Usage of the Monitor

When choosing your work-space, select a sturdy, level surface. Also, make sure you can easily access the back of the monitor. Easy access helps ensure a smooth set-up of the monitor.

**Note:** Before setting up your monitor, refer to the Important Safety Instructions chapter at the beginning of this document.

1. Turn off your device. You should always turn off the device before connecting or disconnecting any device.
2. Example of cable connection: Connect one end of the VGA cable to the VGA connector on the monitor. Connect the other end to your application's VGA connector.
3. Plug the monitor's power cable into the power supply.
4. Press the "Power" (ON/OFF) button.

After pressing the "Power" button, it will take approximately 6 sec. until the monitor is ready and the display is visible.

These are the various power states of the LED monitor represented by the different LED colors on the POWER button:

BLUE: On


Blue light flashing: No signal input

BLANK: Off or No power supply

## 6. OSD Menu Configuration

The layout of the OSD will change depending on the input that is selected.

- Press the MENU button to access the OSD menu.
- Press  $\wedge$  /  $\vee$  to switch between the five menus.
- After having selected a menu, press MENU to select a menu item. Press  $\wedge$  /  $\vee$  to adjust the settings of this item.
- To go to another menu, press the MENU button again to return to the previous menu and go with the  $\wedge$  /  $\vee$  button to the desired menu. Press SOURCE to select a menu item and press  $\wedge$  /  $\vee$  to adjust the settings of this item.
- Press the MENU button to exit the OSD Menu.



## 7. OSD Menu


### 7.1. Picture Menu

The Picture menu can set the color temperature, and the contrast & brightness. Press the  $\wedge$  or  $\vee$  button to adjust the value when an item is selected. Press the MENU button to exit.



## 7.2. Sound Menu

The Sound menu can set the balance, automatic volume calibration, bass & treble, and the sound mode. Press the  $\wedge$  or  $\vee$  button to adjust the value when an item is selected. Press the MENU button to exit.




## 7.3. Screen Menu

The Option menu can adjust the OSD language setting, restore the monitor back to factory defaults, adjust the H- & V-position, adjust the power level in use by backlight, and enable / disable auto sleep. Press the  $\wedge$  or  $\vee$  button to adjust the value when an item is selected. Press the MENU button to exit.



#### 7.4. Function Menu

The Function menu can adjust the H-start, V-start, H-size, and V-size. Press the  $\wedge$  or  $\vee$  button to adjust the value when an item is selected. Press the MENU button to exit.



#### 7.5. Source Menu

The Source menu can select the channel (input). The options include VGA, HDMI and so on. Press the  $\wedge$  or  $\vee$  button to adjust the value when an item is selected. Press the MENU button to exit.

## 8. Frequently Asked Questions

The Power button does not respond:

- Check the power cord to ensure that it is securely plugged into the monitor base and also into the electrical outlet.
- Ensure that there is electrical power coming from the AC outlet. Use another device to check the power.
- Unplug the power cord of the monitor from the AC outlet, wait a few minutes, then plug the power cord into the AC outlet again. This will reset the monitor and power supply.

No image on the screen:

- Ensure that the video signal cable (HDMI, DB-15, CVBS) is properly connected to the display card/computer.
- Check the video signal cable (HDMI, DB-15, CVBS) connector on both ends for bent or pushed-in pins.
- The display card should be properly seated in its card slot.
- Ensure that the computer's power switch is ON.
- Ensure that the monitor's power switch is ON.
- Unplug the power cord of the monitor from the AC outlet, wait a few minutes, then plug the power cord into the AC outlet again. This will reset the monitor and power supply.

The Power LED is blinking (with no image on the screen):

- Check the video signal cable (HDMI, DB-15, CVBS) to ensure that it is properly attached to the graphics display card.
- Check the video signal cable (HDMI, DB-15, CVBS) on both ends for bent or pushed-in pins.
- Make sure the computer is not in a power-saving mode (move the mouse or press a key on the keyboard).

No sound coming from the audio speakers:

- The audio cable should be connected to the line-out on the audio card and the line-in on the monitor. Ensure that the audio cable is properly connected.
- Inspect the audio cable for any apparent damage. Double-check by switching to another audio cable to see if the audio works.

UG-GD-ML-BP3230HD-2021-08-19-V5-EN ©ABETECHS GMBH, DÜSSELDORF, GERMANY

[grundig-security.com](https://grundig-security.com)

**GRUNDIG**